

Morpod Instructions

Parts in package:

- A. Base w/legs and level
- B. Lower Tube w/gold stabilizer
- C. Center Tube
- D. Upper Tube w/camera mount
- E. Boom Clutch w/rotating pads

Steps:

1. Place Base (A) on flat surface/ground. Fan out the two swing legs so that the three legs are equal distant apart, approximately 120° .
2. Slide Lower Tube (B) into the Base (A) unit as shown. The top of the Lower Tube (B) has two plastic screws that will be used in the next step. The gold stabilizer, adjustable by height, is to be connected to the stationary leg of the Base (A), be sure the unit is faced in the way so this is possible. Tighten the black plastic screws on the Base (A) so that the Lower Tube (B) stays firmly in place. Attach gold stabilizer to the stationary leg of the Base (A).
3. Slide the exposed silver metal portion of the Center Tube (C) into the hole at the top of the Lower Tube (B). Tighten the black plastic screws of the Lower Tube (B) so that the Center Tube (C) sits firmly in place.
4. This step is combining the Upper Tube (D) with the Boom Clutch (E). The top of the Upper Tube (D) has the gold adjustable camera mount. Notice that the Boom Clutch (E) unit has two small tubes, each with two plastic screws. On the side of the Boom Clutch (E) is a large knob that tightens and releases the rotating pads. For assembly purposes, keep the pads tight together. Starting from the bottom of the Upper Tube (D), slide either tube of the Boom Clutch (E) far enough in so that the two plastic screws have something to tighten into.
5. Taking this new piece, with the camera mount facing up, slide the unused tube of the Boom Clutch (E) into the top of the Center Tube (C). Slide past the two plastic screws on the Center Tube (C) so that each of them has something to tighten into.
6. Now assembled, loosen then tighten sets of screws to adjust heights of different Morpod pieces. Loosen the big knob on the Boom Clutch (E) to see how the Upper Tube (D) can be shaped. Notice the octagonal shape of the pads themselves; line them up to easily place the tube in 45° and 90° angles.

Note: These are the recommended instructions for assembling the Morpod. Due to the nature of how the tubes fit together, this equipment can be put together in many different ways and with customizations for left and right-handed use. For example, you can slide the Upper Tube (D) directly into the Center Tube (C) to create a standard tripod without using the Boom Clutch (E) at all, if that serves your purposes better. Be sure to tighten all the screws that keep the different parts in place for optimal sturdiness and check them before you attach any equipment to the camera mount. Enjoy your Morpod!