

Unopod™ Instructions

Steps:

1. The Unopod™ requires no assembly. Attach a still or video camera to the gold mounting head using the #1/4-20 camera mounting stud.
2. Adjust the height of the Unopod™ by turning the knobs on the side of the tubes, loosening their grip, and sliding the 3 independent t-tracks up and down. Tighten those same screws to lock the height in place.
3. Steady the Unopod™ by stepping down on the foot pedal and tightening all adjustment knobs.